




EN HOW TO INSTALL LED (ASSEMBLY GUIDE)

DE AUFBAUANLEITUNG FÜR LED POP-UP

1



x3/x4 x9/x12/x16

EN

LED set 3x3 contains:

- 9 LED curtain 30 W
- 3 AC adaptor (~2,3 m cord)
- soft carry bag
- extension cord (~2,8 m)

LED set 4x3 contains:

- 12 LED curtain 30 W
- 4 AC adaptor (~2,3 m cord)
- soft carry bag
- extension cord (~2,8 m)

LED set 4x4 contains:

- 16 LED curtain 30 W
- 4 AC adaptor (~2,3 m cord)
- soft carry bag
- extension cord (~2,8 m)

DE

LED-Set 3x3 besteht aus:


- 9 LED-Vorhänge 30 W
- 3 AC-Adapter (Kabel ~2,3 m)
- Transporttasche
- Verlängerungskabel (~2,8 m)

LED-Set 4x3 besteht aus:


- 12 LED-Vorhänge 30 W
- 4 AC-Adapter (Kabel ~2,3 m)
- Transporttasche
- Verlängerungskabel (~2,8 m)

LED-Set 4x4 besteht aus:

- 16 LED-Vorhänge 30 W
- 4 AC-Adapter (Kabel ~2,3 m)
- Transporttasche
- Verlängerungskabel (~2,8 m)



2




EN

Instal LED before putting graphics on the system.

DE

Die LED-Vorhänge müssen vor dem Grafikeinsatz montiert werden.

③



④

